



Place this printout over the wood and mark drill holes.
Drill standoff holes to a depth of 1/4 inch with a 1/4 inch brad point bit.
Holes can be drilled with a hand drill but a drill press works better.



Wood Block 6 x 8.25 inches
3/4 inch thick or better

